



Urinal Cleaning

*dissolves water scale, calcium, rust
& urinal salt deposits safely, quickly and effectively!*

Deposit Removal within Urinals

For Slow Draining Urinals:

1. Pour 8 oz. of **Eco Descal** into the urinal drain.
2. Wait 15 minutes.
3. Flush the urinal.
4. Repeat steps 1 through 3, if necessary.

