



Waterless Urinal Cleaning

*dissolves water scale, calcium, rust
& urinal salt deposits safely, quickly and effectively!*

Deposit Removal within Waterless Urinals

For Slow Draining Waterless Urinals:

1. Take the metal tool provided by the manufacturer to remove the trap.
2. Insert tool into the trap, gently pulling it out using a back and forth motion.
3. Drain any excess liquids from the cylinder down the drain, and then discard in a locally appropriate manner.
4. With the trap removed, pour 16 ounces of **Eco Descale** in the drain to flush any sediment in the line; wait 15 minutes.
5. Pour water into trap to assure flow; repeat if necessary.
6. Insert a new trap, add about 12 ounces of water, and fill with three ounces of sealant.
7. For some manufacturers, the trap cannot be replaced and the trap needs to be taken apart and cleaned with **Eco Descale**.

